





Tools needed



1st step: Driver update


- 1 Save the .drv file with the driver update to install in the root of a USB stick. Never change the Driver's file name. Make sure the EVO panel is in CCT mode
- 2 Connect the USB stick with the cable (Mini USB male to USB female), provided by VELVET or your authorized dealer.
- 3 Connect the USB memory+USB cable set to the EVO
With the EVO unit turned OFF, simultaneously press   and turn ON the equipment.
- 4 A screen with a software update message will automatically appear on the display. Wait for the progress bar to complete and the screen shows: DRIVER UPDATE DONE!



- 5 Turn the EVO OFF and ON again


Proceed to the second step

Tools needed



2nd step: Firmware update

- 1 Save the .frm file with the firmware update to install in the root of a USB stick. Never change the Firmware file's name. Always match the fixture model to its dedicated firmware file. Turn ON the equipment and check that the EVO panel is in CCT mode
- 2 Press to select "Settings". Select "ABOUT" with and press and press
- 3 Select "FIRMWARE UPDATE" and press to start the process



- 4 Connect the USB memory + USB cable set when the EVO unit asked you
- 5 Once the firmware update process is finished, the display will show: "UPDATE DONE!". The EVO panel will proceed to reboot with the new firmware.

If you have problems with your device or with the update, please contact us at: customer@velvetlight.tv

Your EVO panel is now updated